



Step 1: Close and fuse all rings (including the large ring you will use for your clasp) separately.

Step 2: Hammer centerpiece and all 3 small rings flat. Texture.

Step 3: Place the Sharpie inside of the large ring for the hook clasp and shape one side of the ring around the Sharpie, closing the other side until there is $\frac{3}{8}$ " between the sides of the ring (**Figure 1**).

Step 4: Hammer the large round part of this clasp flat and texture (**Figure 2**). Do not hammer the hook side of the clasp yet.

Step 5: Turn the clasp over and hammer the hook part flat; texture (**Figure 3**).

Step 6: Place the hook part of the clasp flat on the brick. Heat until faintly glowing orange (make sure to stop short of the metal becoming "flowy"!) and quench. This will anneal the metal and make it softer and more pliable for Step 9.